

**Products:**

Gubi Chair shell – wood front upholstered, 4-leg wooden base – non stackable, 4 pcs M6x20 flat head screw, 4 pcs rubber washer,

**Tools:**

Akku drill or screwdriver with Unbraco 4 bit

**Products:**

Gubi chair shell – wood front upholstered.

**Action:**

Turn the shell upside down, so the holes on the backside of the seat is visible and faces upwards.

**Products:**

Gubi chair shell – wood front upholstered, Würth DOS thread locking agent MEDIUM, Art. No. 0893243050

**Action:**

Apply a suitable amount of the locking agent in the 4 pcs mounting holes

**Products:**

4 pcs M6x20 Unbraco 4 flat head screw from Disosols, 4 pcs rubber washer 47x4,9x3 mm EPDM 80 sh Klinger Danmark Art. No. 2925.



**Products:**

4-leg wooden base – non stackable, 4 pcs flat head screw

**Action:**

Put 1 screw through the bottom of the wooden base.



**Products:**

4-leg wooden base – non stackable, 4 pcs flat head screw, 4 pcs rubber washer

**Action:**

Place a rubber washer on top of the screw on the top side of the wooden base.



**Products:**

4-leg wooden base – non stackable, 4 pcs flat head screw, 4 pcs rubber washer

**Action:**

Press the rubber washer down on the top of screw.



**Products:**

4-leg wooden base – non stackable, 4 pcs flat head screw, 4 pcs rubber washer

**Action:**

The rubber washer will now hold the screw fixed to the wooden base.



**Products:**

4-leg wooden base – non stackable, 4 pcs flat head screw, 4 pcs rubber washer

**Action:**

Now do the same with the rest of the screw, so all 4 screws are fixed to the wooden base



**Products:**

Gubi chair shell – wood front upholstered, 4-leg wooden base, 4 pcs M6x20 flat head screw, 4 pcs rubber washer

**Action:**

Place the wooden base with the fixed screws on top of the shell, so the screws in the base catches the holes in



**Products:**

Gubi chair shell – wood front upholstered, 4-leg wooden base, 4 pcs M6x20 flat head screw, 4 pcs rubber washer

**Action:**

Make sure that all screws are correct into the thread in the shell.



**Action:**

The M6 screws can be tightened with a screwdriver or an Akku drill.





**Action:**

Please make sure all screws are tightened properly.



**Action:**

Turn the chair around and place it on the legs.  
The Gubi chair is ready for use.

